



ENGINE MAKE . . . . . Continental  
OEM CARBURETOR NO . 633028

020014

CARBURETOR NO . . . . A10-4894  
MODEL NO. . . . . MA-3SPA  
FLOAT SETTING . . . . 7/32"

Ref. No.	Part No.	Qty.	Description	Ref. No.	Part No.	Qty.	Description
1	10-4231	1	Carburetor Bowl Assy.	37	46-A70	1	Venturi - Main (1 - 1/2")
2	<b>12-B57</b>	1	Lever - Throttle, Serrated	38	<b>47-799</b>	1	Nozzle Assy.
3	<b>13-1520</b>	1	Throttle Lever & Stop Assy., Serrated Stop	39	55-A139	1	Retainer - "O" Ring, Mixture Metering Valve Head
4	14-189	1	Valve - Throttle	40	<b>60-260</b>	2	Bushing - Throttle Shaft
5	15-42	1	Screw - Throttle Adjusting	41	66-14	1	Lockwire - Pump Lever Screw
6	<b>15-58</b>	2	Screw - Throttle Valve	42	<b>66-18</b>	1	Lockwire - Mixture Control Valve Head
7	15-223	1	Screw - Idle Drill Plug				
8	15-A1	1	Screw - Pump Lever Pin	44	78-121	2	Washer - Pump Inlet Strainer Housing Screw
9	15-A14	2	Screw - Pump Inlet Strainer Housing	45	78-184	2	Washer - Mixture Control Valve Spring (1) Mixture Control Valve Thrust (1)
10	15-A21	2	Screw - Float Bracket	46	<b>78-356</b>	1	Washer - Horseshoe (Mixture Control Valve Head)
11	15-B107	4	Screw - Throttle Body to Bowl	47	<b>78-388</b>	1	Washer - Pump Stem Packing Retainer
12	15-B108	1	Screw - Mixture Control Lever	48	<b>78-A109</b>	1	Washer - Mixture Control Lever Screw
13	16-222	1	Gasket - Nozzle	49	<b>78-A110</b>	4	Washer - Throttle Body to Bowl Screw
14	16-224	1	Gasket - Float Valve Seat	50	<b>81-311</b>	1	Nut - Lock, Throttle Lever
15	<b>16-696</b>	1	Gasket - Kit	51	<b>82-11</b>	3	Pin - Cotter (Float Lever Shaft (1) (Pump Link (2)
16	16-A16	1	Gasket - Strainer Housing	52	82-14	1	Pin - Cotter, Throttle Lever Lock Nut
17	16-A28	1	Gasket - Pump Discharge Check Valve	53	95-54	1	Screen - Pump Inlet Strainer
18	16-A36	1	Gasket - Fuel Inlet & Strainer Assy.	54	95-75	1	Screen - Nozzle & Idle Air Vent
19	16-A107	1	Gasket - Power Jet	55	95-509	1	Strainer & Fuel Inlet Assy.
20	16-B45	1	Gasket - Pump Discharge Check Valve Assy.	56A	99-8	1	Plug - Bowl Drain
21	16-B75	1	Gasket - Throttle Body to Bowl	56	99-34	1	Plug - Pump Discharge Check Valve
22	<b>17-383</b>	1	Rod - Pump Connecting	57	110-173	1	Retainer Flange - Pump Inlet Strainer Housing
23	24-262	1	Spring - Throttle Adjusting Screw	58	136-58	1	Bracket - Float
24	24-480	1	Spring - Mixture Control Valve Head	59	155-307	1	Lever - Pump
25	24-A1	1	Spring - Idle Adjusting Needle	60	155-629	1	Mixture Control Lever Assy.
26	<b>29-113</b>	3	Clip - Venturi Retainer	61	<b>194-593</b>	1	Pump Plunger Assy.
27	29-184	1	Clip - Float Valve (Used with 30-628)	62	221-76	1	Housing - Pump Inlet Strainer
27A	29-193	1	Clip - Float Valve (Used with 30-759)	63	227-1612	1	Throttle Body Assy.
28	30-759	1	Float & Lever Assy.	64	229-550	1	Pump Discharge Tube Assy.
29	<b>32-32</b>	1	Shaft - Float Lever	65	<b>229-587</b>	1	Idle Tube Assy.
30	36-525	1	Pump Inlet Check Valve Assy.	66	<b>233-615</b>	1	Float Valve, Seat & Gasket Assy.
31	36-540	1	Pump Discharge Check Valve Assy.	67	242-514	1	Mixture Control Metering Valve Assy.
32	37-7	1	Ball - Lead Plug (Idle Drill)	68	286-1636	1	Repair Kit
33	43-564	1	Needle - Idle Adjusting				
34	<b>44-49</b>	1	Packing - Pump Stem				
35	44-223	1	Packing - "O" Ring, Mixture Metering Valve Head				
36	46-A33	1	Venturi - Primary				

Rev. 8 - 79